



**4:1 10-bit 1.2 Gsps MUXDAC
Evaluation Kit - TSEV86101G2B**

.....
User Guide

Table of Contents

Section 1

Introduction	1-1
1.1 Description	1-1
1.2 MUXDAC Evaluation Kit	1-1

Section 2

General Description	2-1
2.1 MUXDAC Evaluation System	2-1
2.2 Block Diagram	2-1
2.3 Hardware	2-2
2.3.1 Board Mechanical Characteristics	2-3
2.3.2 Board Layout Information	2-4
2.4 Software	2-5

Section 3

Getting Started	3-1
3.1 Software Installation	3-1
3.1.1 Platform Requirements	3-1
3.1.2 Installation Procedure	3-1
3.2 Hardware Setup	3-8
3.2.1 Power Supply Requirements	3-8
3.2.2 HF Clock	3-8
3.2.3 Analog Output	3-8
3.2.4 Option Selections	3-9
3.2.5 Startup Procedure (Stand-alone Mode)	3-10
3.2.6 Startup Procedure (PC Driven Mode)	3-10
3.2.7 Diode Temperature Monitoring	3-10
3.2.8 Frequency Fcw	3-11
3.2.9 Troubleshooting	3-11

Section 4

Operating Modes	4-1
4.1 Overview	4-1
4.2 Pattern Management	4-2
4.2.1 Typical Operation Flow	4-2
4.3 Error Messages	4-4

Section 5

Ordering Information	5-1
----------------------------	-----

Section 6

Appendix I: Pattern Formats	6-1
6.1 Pattern Structure	6-1
6.2 Vector Structure	6-1
6.2.1 First Example	6-1
6.2.2 Second Example	6-2
6.3 Patterns Furnished on the CD-ROM	6-2

Section 7

Appendix II:	
Pattern Generator Software	7-1

Section 1

Introduction

-
- | | | |
|------------|------------------------------|--|
| 1.1 | Description | <p>The TSEV86101G2B Evaluation Board (EB) is a prototype board which has been designed in order to facilitate the evaluation and characterization of the TS86101G2B MUXDAC device (CBGA255 cavity up packaged device) over an output band of interest of up to 300 MHz, at 600 Msps maximum conversion rate (Sampling Rate limited by the FPGA performance only).</p> <p>The TSEV86101G2B Evaluation Kit contains all the software and hardware necessary to setup the board and perform its characterization.</p> <p>The evaluation system of the TS86101G2B MUXDAC device consists in a configurable printed circuit board (the Evaluation board itself), including the soldered MUXDAC device (CBGA255 package), an FPGA chip, a serial interface to a Windows95® or Windows98® computer and a user interface running on that platform.</p> |
| <hr/> | | |
| 1.2 | MUXDAC Evaluation Kit | <p>The MUXDAC evaluation kit contains:</p> <ul style="list-style-type: none">■ 1 MUXDAC evaluation board■ 1 CD-ROM that contains the User Interface Installation Software, the User Manual, the Pattern Generator Software, and some pattern files. |

Section 2

General Description

2.1 MUXDAC Evaluation System


The MUXDAC evaluation system consists of:

- A configurable printed circuit board, including a soldered MUXDAC in a CBGA255 package
- An FPGA
- A serial interface to a computer running Windows® 95/98
- A user interface running on the above platform

500 x 40-bit max test patterns are loaded into the FPGA and applied to the MUXDAC.

2.2 Block Diagram

Figure 2-1. Block Diagram



2.3 Hardware

Figure 2-2. MUXDAC Printed Board Circuit




Figure 2-2 show, from left to right: Serial interface connector, FPGA surrounded with termination resistors and 50Ω tracks, MUXDAC area, sampling delay rotating switch, SMA connectors for differential clock and output.

From top to bottom: FPGA glue logic (Status leds, reset button, serial interface crystal, configuration EPROM), MUXDAC power connectors (4 mm plugs), FPGA and MUXDAC, clock interface (delay line with 2 programming switches, differential to single ended interface), FPGA power connectors (4 mms plugs).

2.3.1 Board Mechanical Characteristics

2.3.1.1 Board Layer Thickness Profile

The board layer numbers, thickness and functions are given below, from top to bottom.

Table 2-1. Board Layer Thickness Profile

Layer	Characteristics
Layer 1 Copper Layer	Copper Thickness = 35 μm AC signal Traces = 50 Ω microstrip lines DC signal Traces (DIODE, CS)
Layer 2 Copper Layer	Copper thickness = 35 μm A_{GND} , D_{GND} (separate traces)
Layer 3 Copper Layer	Copper thickness = 35 μm AC Signal Traces = 50 Ω microstrip lines (Input Data)
Layer 4 Copper Layer	Copper thickness = 35 μm A_{GND} , D_{GND} (separate traces)
Layer 5 Copper Layer	Copper thickness = 35 μm MUXDAC V_{CC} , FPGA +1.5V supply
Layer 6 Copper Layer	Copper thickness = 35 μm Separate V_{EEA} and V_{EED} FPGA +2.5V and +3.3V supplies
Layer 7 Copper Layer	Copper thickness = 35 μm A_{GND} , D_{GND} (separate traces)
Layer 8 Copper Layer	Copper thickness = 35 μm AC signal Traces = FPGA signals
Layer 9 Copper Layer	Copper thickness = 35 μm A_{GND} , D_{GND} (separate traces)
Layer 10 Copper Layer	Copper thickness = 35 μm AC signal traces = 50 Ω microstrip lines (MUXDAC Input Data)

The TSEV86101G2B Evaluation Board is a nineteen layer PCB board made of 10 copper layers and 9 dielectric layers.

The metal layers correspond respectively from top to bottom to stages of two AC signal trace planes (MUXDAC or FPGA) with one ground plane ($A_{\text{GND}}/D_{\text{GND}}$) in between.

The metal layers are isolated from one to another by HTG epoxy layers.

Dielectric layer thickness:

- Between layers 1 and 2, 9 and 10: 200 μm
- 350 μm for all other layers

Dielectric constant: $\epsilon_r = 4.1$ at 1 MHz

Insertion Loss: -0.01 dB/inch at 1 MHz


The previously described mechanical and frequency characteristics make the board particularly suitable for device evaluation and characterization in the high frequency domain and in a wide temperature range.

2.3.1.2 Input Accesses	<p>The board inputs (which correspond to the FPGA inputs) are accessed via an RS-232 serial port (9 points pin to pin connector with the RX and TX pins not inversed).</p> <p>The Clock input is accessed via SMA connector.</p>
2.3.1.3 Output Accesses	<p>The board outputs are accessed differentially via SMA connectors.</p>
2.3.1.4 Power Supplies and Ground Accesses	<p>The MUXDAC power supplies (V_{EED}, V_{EEA}, V_{CC}) are accessed via banana jacks (4 mm plugs).</p> <p>The FPGA power supplies (+1.5V, +2.5V, +3.3V) are accessed via banana jacks (4 mm plugs).</p>
2.3.1.5 Function Setting Accesses	<p>The DIODE Function for die junction temperature monitoring is accessed via a 2 mm banana jack.</p> <p>The CS (shift select for DSP clock) function is accessed through a coding wheel.</p>
2.3.2 Board Layout Information	<p>In order to evaluate the TS86101G2B MUXDAC device easily and efficiently, two options were explored. The first one required the use of a pattern generator, which could be a costly solution for many users. The second option was to use an FPGA, which would provide specified patterns to the MUXDAC, as well as the MUXDAC input clock.</p> <p>Although the later option would limit the speed range of the evaluation (the maximum frequency attainable at the output of the MUXDAC, namely 600 Msps, is limited by both the FPGA output frequency capabilities and the memory widths), it was preferred to the former option because it provided a more flexible way to characterize the MUXDAC device.</p> <p>Because of the use of an FPGA, additional care had to be taken with the board layout, in order to separate effectively the MUXDAC signal traces from the FPGA signal traces as well as the ground traces.</p> <p>The following puts forward the board layout recommendations and demonstrates how the evaluation board fulfills the many implementation constraints.</p>
2.3.2.1 Digital Inputs/Analog Outputs	<p>The board uses 50Ω impedance microstrip lines for the digital data and clock inputs and analog outputs. The input and clock signals are routed on one layer only, without using any through-hole via.</p> <p>The lines connecting the FPGA to the MUXDAC are 50Ω lines.</p>
2.3.2.2 DC Function Settings	<p>The DC signal traces are low impedance.</p>
2.3.2.3 Power Supplies	<p>Layers 9 and 11 are dedicated to the MUXDAC and FPGA power supply traces (V_{CC}, V_{EED}, V_{EEA} and +1.5V, +2.5V and +3.3V).</p> <p>The supply traces are routed in order to present low impedance, and are surrounded by ground planes (layers 7 and 13).</p> <p>The analog and digital negative power supply traces are independent, but the possibility exists to short-circuit both supplies on the top metal layer.</p> <p>Each incoming power supply is bypassed by a 1 μF Tantalum capacitor in parallel with a 10 nF capacitor. Each power supply access is decoupled by a 10 nF capacitor and a 100 pF surface mounted chip capacitors in parallel, located as close as possible to the device.</p> <p>Note: The decoupling capacitors are superimposed. In this configuration, the 100 pF capacitor must be mounted first.</p>

2.4 Software

The MUXDAC evaluation user interface software is a LabVIEW™ compiled graphical interface, that requires no license to run on a Windows® 95/98.

Figure 2-3. MUXDAC User Interface



Note: The software uses intuitive buttons and pop-up menus to send data to the MUX-DAC.

Section 3


Getting Started

3.1 Software Installation

3.1.1 Platform Requirements

A PC running Windows® 95/98, with an RS-232 serial port is required.

Figure 3-1. Contents of the Installation Compact Disk




3.1.2 Installation Procedure

The installation is performed in 3 steps:


1. Install the Muxdac10bit 4-1 v1.0.
2. Install the NI LabVIEW™ Run Time Engine 6.0.
3. Install the NI-VISA driver.

3.1.2.1 To Install the Software on a PC

1. Install the Muxdac10bit 4-1 v1.0
 - 1.1. Insert the CD-ROM.
 - 1.2. Open an Explorer window.
 - 1.3. Double-click on D:\Installer10bit 4-1\setup.exe.

Figure 3-2. D:\Intaller 10bit 4-1 Contents

- 1.4. A setup window appears (see Figure 3-3) and suggests installing the program in C:\Program Files\MuxDac\10bit 4-1:

Figure 3-3. Muxdac 10bit 4-1 V1.0 Intallation Window

- 1.5. Click on *Finish* to continue the installation.


1.6. A window appears (see Figure 3-4) to confirm that the installation is successful.

Figure 3-4. Muxdac Installation Dialog Box




A directory named *C:\Program Files\MuxDac\10bit 4-1* is created with an executable software (this window does not appear when installing the software).

Figure 3-5. *C:\Program Files\MuxDac\10bit 4-1* Contents



1.7. The MuxDac 10Bit 4-1.exe software is automatically added to the Startup Menu\Programs\MuxDac 10bit 4-1 ("Menu Démarrer\Programmes" in the French version). A window appears (see Figure 3-6) to indicate that Muxdac 10bit 4-1 executable file is installed.

Figure 3-6. MuxDac 10Bit 4-1.exe Software



2. Installation of NI LabVIEW™ Run Time Engine 6.0

If LabVIEW™ is not installed on your PC, it is necessary to install this free NI LabVIEW™ software.

- 2.1. When the first step has been successfully completed, a window appears (see Figure 3-7). Install Run Time Labview Engine 6.0.

Figure 3-7. 1st LabVIEW Run-Time Engine Setup Window



- 2.2. Click on *Next* to continue the installation. A window appears (see Figure 3-8) and suggests installing the program in C:\Program Files\National Instruments\

Figure 3-8. 2nd LabVIEW Run-Time Engine Setup Window



- 2.3. Click on *Next* to continue the installation. When the installation is finished, Figure 3-9 appears.

Figure 3-9. 3rd LabVIEW Run-Time Engine Setup Window



- 2.4. Click on *Finish* to terminate the installation.

3. Installation of NI-VISA software

If LabVIEW™ is not installed on your PC, it is necessary to install this free NI LabVIEW™ software.


- 3.1. Double-click on D:\Installer10bit 4-1\NI-VISA2.5.2\setup.exe.
3.2. Figure 3-10 appears. Click *Next* to continue the installation.

Figure 3-10. 1st NI-VISA Setup Window




3.3. When the installation is finished, Figure 3-11 appears. Click on *Finish* .

Figure 3-11. 2nd NI-VISA Setup Window



- 3.4. Figure 3-12 appears and ask you to restart your computer. Click on Yes to restart your computer.

Figure 3-12. NI-VISA Installer Dialog Box



3.1.2.2 Installation Testing



1. Select the program *MUXDAC 10bit 4-1 v1.0* from the Startup/Program menu or double-click on *C:\Program Files\MuxDac\10bit 4-1\MuxDac 10Bit 4-1.exe*.
2. Figure 3-13 will be displayed.
There must be no error message and the Error display must not be highlighted.
If an error is detected, the Error display is highlighted: .
Simply click on *QUIT*, and close the MUXDAC window.

Figure 3-13. MUXDAC User Interface



3.1.2.3 Troubleshooting

1. Check that the C:\ hard disk is properly mounted.
2. Check that you have the right to write in the directory.
3. Check for available disk space.
4. Check that the serial COM port is free and properly configured.
5. Check that the serial COM port is exactly declared with *C:\Program Files\MuxDac\10bit 4-1\MuxDac 10Bit 4-1.ini* file.

3.2 Hardware Setup

3.2.1 Power Supply Requirements

3.2.1.1 FPGA

- Core: 2.5V +10/-5% (Keep core voltage as high as possible for higher speed and assume current of 1A at 1 GHz)
- Periphery: 3.3V \pm 5%
- D_{GND}: 0V reference voltage

The core and periphery supplies should be switched on at the same moment.

3.2.1.2 Termination Voltage

1.2V – 1.6A typ., 1.5V max (2A)

3.2.1.3 MUXDAC

See Specifications on Section 2.

- V_{EEA}: analog ECL voltage, -5.0V (0.4 to 0.6A)
- V_{EED}: digital ECL voltage, -5.0V
- V_{CCD}: digital PECL voltage, +5.0V
- A_{GND}: 0V reference analog voltage
- D_{GND}: 0V reference digital voltage

V_{EEA}, V_{EED} and V_{CCD} supplies should be switched on at the same moment (otherwise, if this is not possible, in the following order: V_{CCD}, V_{EEA} then V_{EED}).

A_{GND} and D_{GND} should be connected together.

3.2.2 HF Clock

Use the HF generator with a 50 Ω output.


100 to 600 MHz, -1 at +5 dBm

3.2.3 Analog Output

Use an oscilloscope and/or a spectrum analyzer with a 50 Ω input.

3.2.4 Option Selections

Figure 3-14. Hardware Description



- S1: FPGA reset push button
- D2: Orange LED, indicating FPGA initialization phase
- D3: Red LED, indicating FPGA initialization errors
- U11: MUXDAC digital inputs delay setting (Hexadecimal coding)
- J10/OPT1: FPGA standalone setting (with jumper: ramp output, else zero output)
- J10/OPT2, 3, 4: RESERVED. Jumper must be plugged in



Do Not Use:

- JP1: JTAG programming mode when jumper is unplugged. Used only for FPGA debugging. The jumper must be plugged in for normal operation.
- J9: 12-pin JTAG connector. Used only for FPGA debugging.

3.2.5 Startup Procedure (Stand-alone Mode)

The HF Clock should be on to provide the Fcw Clock to MUXDAC through the J13 SMA connector.

The MUXDAC should be started first: V_{EEA} , V_{EED} and V_{CCD} supplies should be switched on at the same moment.

Jumper OPT1 may be unplugged (no jumper on OPT1).

When the MUXDAC is ready, FPGA can be powered on. The core 2.5V and periphery 3.3V supplies should be switched on at the same moment, the terminal voltage 1.2V must be the last FPGA supply to stabilize in order to properly activate the power-on-reset circuit, and start initialization. The orange LED lights during the EPROM download phase, then turns off. No LED must light after initialization.

After startup, it is recommended to reset the FPGA, to lock the internal PLL on a stable clock. It's only after reset that the OPT1 jumper may be plugged in to switch to the default (ramp) pattern.

3.2.6 Startup Procedure (PC Driven Mode)

The HF Clock should be on to provide the Fcw Clock to MUXDAC through the J13 SMA connector.

MUXDAC should be started first: V_{EEA} , V_{EED} and V_{CCD} supplies should be switched on at the same moment.

The startup option must be set to the Zero mode for a clean startup of the MUXDAC (no jumper on OPT1).

When the MUXDAC is ready, FPGA can be powered on. The core 2.5V and periphery 3.3V supplies should be switched on at the same moment, the terminal voltage 1.2V must be the last FPGA supply to stabilize in order to properly activate the power-on-reset circuit, and start initialization. The orange LED lights during the EPROM download phase, then turns off. No LED must light after initialization.


After startup, it is recommended to reset the FPGA, to lock the internal PLL on a stable clock.

When the FPGA is ready, run the *MuxDac 10Bit 4-1.exe* software.

3.2.7 Diode Temperature Monitoring

The DIODE Pad Temp is provided for die junction temperature monitoring.


Figure 3-15. Diode Temperature Monitoring



For a given forced current in Pad Temp, the voltage across the diode mounted transistor depends linearly on the temperature. Since the characteristic of the diode may vary from deviate device, the voltage across the diode must first be measured for a known junction temperature.

The measured diode mounted transistor, V_{be} , values as a function of junction temperature at $I = 1 \text{ mA}$ are given below.

Figure 3-16. Junction Temperature Monitoring



3.2.8 Frequency Fcw

The frequency of HF clock can be changed without turning off the board and MUXDAC. But it is recommended that the FPGA be reset in order to lock the internal PLL on a stable clock. During reset, OPT1 jumper may be unplugged.

3.2.9 Troubleshooting

3.2.9.1 Orange LED Remains Alive

- Jumper JP1 is not plugged (FPGA in JTAG mode): plug in a jumper
- Bad PLL lock: power off the MUXDAC, and restart FPGA
- Power problem (bad 3.3V rise time): check 2.5 and 3.3V voltage
- Restart the 3.3V power supply, unplug and replug the 3.3V connector or, change the 3.3V power supply

3.2.9.2 Red LED Remains Alive

- Same as the Orange LED
- Check if an EPROM is properly plugged in the U4 socket

- 3.2.9.3 1.2V Supply Overloaded**
- Weak power supply: 1.7A typ required
 - Bad PLL lock: power off the MUXDAC, and restart FPGA
 - Check for possible shorts
- 3.2.9.4 2.5V Supply Overloaded**
- Weak power supply: 1A typ required
 - Check for possible shorts
- 3.2.9.5 MUXDAC Supplies Overloaded**
- Check for possible shorts (beware of SMT components below socket)
- 3.2.9.6 Permanent COM Errors**
- Reset FPGA, Reset Software (RESET button)
 - Exit and restart the software
 - Verify that MUXDAC board is connected to COM1
 - Verify that COM1 is configured properly (even parity, 1 stop bit, LSB first, 9600 baud, RTS, DTR signals)
 - Test FPGA initialization (LEDs, clocks, MUXDAC signals)
 - Reset FPGA and check MUXDAC signals, MUXDAC clock (OPT1 maybe unplugged)
 - The RS-232 serial interface should NOT have the RX and TX pins inversed.
- 3.2.9.7 MUXDAC to FPGA Clock Problems**
- Check for possible shorts (beware of conflicts between the delay line and the MUXDAC)
 - Check inputs and outputs from the differential to the single ended converter
 - Check the high frequency clock connections (J13 SMA) and settings (frequency, level)
 - Check FPGA initialization (PLL locked)
- Note:** When restarting the user interface software, always reset the FPGA before sending a pattern.

Section 4

Operating Modes

4.1 Overview

The MUXDAC is intended to feed a device under test with predefined patterns, stored on the host computer, in order to observe and measure most converter performances.

The evaluation system is build around an FPGA, providing an internal pattern capacity of 20 Kwords RAM, organized as 512 40-bit rows. Once loaded into the FPGA memory, test patterns are looped back indefinitely, under software control. Four 10-bit words are applied to the device under test, using differential signaling every rising edge of the FPGA fast clock. In order to ease synchronization, the differential clock for pattern sampling is regenerated within the FPGA and propagated to the MUXDAC.

The software provides a graphical user interface to configure the FPGA pattern generators, store test vectors in the board memory, and control execution. Buttons and pop-up menus allow the user to easily perform:

- Pattern file selection
- Pattern memory downloading into the board pattern memory

The computer interface uses a standard asynchronous serial port. The serial port is organized as a byte oriented data flow running at 9600 baud, even parity, single stop bit, positive logic signaling, LSB first. The transfer protocol makes use of the DTR and RTS lines for synchronization.

The automatic configuration provides users with simple access to basic operations (pattern initialization, pattern start and stop) without any knowledge about the board or the software's internal structure.

4.2 Pattern Management


Test pattern generation and test pattern format are detailed in Section 6 and Section 7.

Writing patterns to the board's RAM memory is transparently handled by the user interface software (length computing, register programming, byte formatting, serial link framing), as long as the pattern format is respected.

4.2.1 Typical Operation Flow


1. Insert the MUXDAC in the socket if the MUX-DAC is not soldered (be careful of Pin 1).
2. Apply the HF clock to the board.
3. Power on the MUXDAC.
4. Power on the FPGA.
5. Connect appropriate test tools to the analog output (oscilloscope, spectrum analyzer, etc...).
6. Start the user interface software.

Figure 4-1. MUXDAC User Interface



7. Reset the FPGA.
8. Check that no error is flagged.
9. Select a pattern.

Figure 4-2. Pattern Selection








- 9.1. Click on  in the user interface Pattern file menu. The *Select pattern file* window pops-up.
- 9.2. Select a pattern file by double-click on the file name. The file name is now displayed in the pattern file box. The Nb vectors and header box indicate information about the pattern file.

Figure 4-3. MUXDAC User Interface



- 9.3. Click on *Send pattern* . Wait until end of transfer file.
10. Start the pattern operation by clicking on *Start*  or press F4 on the keyboard.
11. Stop the pattern operation by clicking on *Stop*  or press F5 on the keyboard.

By default, the path used to select a pattern file is the one defined in:


C:\Program Files\MuxDac\10bit 4-1\MuxDac 10Bit 4-1.ini

This default path can be changed by modifying the item PatternDir of the file *MuxDac 10Bit 4-1.ini*

By default, there is a single pattern file which is:

C:\Program Files\MuxDac\10bit 4-1\600M_264.9M_0.0dBFS.txt

4.3 Error Messages *Figure 4-4. Communication Problem Dialog Box*



- Check that the evaluation board is powered ON.
- Check the serial interface cable.
- Check serial port settings (even parity, 1 stop bit, lsb first, 9600 baud, RTS, DTR signals).
- Reset or reinitialize FPGA (power off 2.5 and 3.3V supplies).
- Check the test pattern file format (if the pattern was modified manually).

Section 5

Ordering Information

Part Number	Package	Temperature Range	Screening Level	Comments
TSEV86101G2BGL	CBGA 255	Ambient	Standard	Contact e2v sales
TS86101G2BCGL	CBGA 255	Commercial grade 0°C < Tc, Tj < 90°C	Standard	Contact e2v sales
TS86101G2BVGL	CBGA 255	Industrial grade –40°C < Tc, Tj < 110°C	Standard	Contact e2v sales
TS86101G2BMGS	CI-CGA255	Tc > –55°C, Tj < 125°C	Standard	Contact e2v sales
TS86101G2BMGS9NB1	CI-CGA255	Tc > –55°C, Tj < 125°C	ESA/ECC	Contact e2v sales
TS86101G2BMGS	CI-CGA255	Tc > –55°C, Tj < 125°C	Standard	Contact e2v sales
TS86101G2BMGS9NBI	CI-CGA255	Tc > –55°C, Tj < 125°C	ESA/ECC	Contact e2v sales

Appendix I: Pattern Formats

The pattern file must be written in a fixed format:

- Plain text file
- 512 pattern lines maximum (board maximum allowed value)

6.1 Pattern Structure As the multiplexing ratio is not a power of 2, care should be exercised to ensure a clean transition when looping back from the last vector line to the first one:

For P 4x10-bit samples per analog signal period sequences, it is recommended that the pattern contains 4 x P words (=> P-1 length integer value). The pixel clock should thus be selected such that $P \leq 512$.

The minimum pattern size has been fixed to 4 vectors. Should the pattern be shorter than 4 vectors, then it must be simply repeated in order to fill at least the requested 4 vectors. The maximum pattern size is 512 lines, which is the maximum memory depth in the FPGA.

6.2 Vector Structure

Vector 0:	1000000000	1000000001	1000000010	1000000011
Bits Vector:	A9.....A0	B9.....B0	C9.....C0	D9.....D0

Use the binary code for pattern bits.

6.2.1 First Example Default pattern ('ramp', 4 first lines from PR file)

File PR.dat
Clock: 600 MHz
Frequency: 10 MHz

Vecteur 0: 0000000001 0000000010 0000000011 0000000100
Vecteur 1: 0000000101 0000000110 0000000111 0000001000
Vecteur 2: 0000001001 0000001010 0000001011 0000001100
Vecteur 3: 0000001101 0000001110 0000001111 0000010000
Etc...

Note: There is no specific structure for the header. All lines preceding the line beginning by *Vecteur 0*: are ignored.

6.2.2 Second Example

Fc: 600 MHz
Fout: 110.1 MHz
Level: 0 dBFS

Vecteur 0: 1000000000 1111010011 1101111011 0101100000
Vecteur 1: 0000000010 0100000010 1100101111 1111110100
Vecteur 2: 1001100110 0001011110 0001000111 1000111011
Vecteur 3: 1111101000 1101010001 0100101000 0000000000
Etc...

This example has the format used by the pattern generator software furnished with the MUX-DAC (see Section 7).

The header displays the clock rate (600 MHz), the frequency Fout of the sinewave to be generated (110.1 MHz) and the amplitude of the sinewave (0 dBFS).

6.3 Patterns Furnished on the CD-ROM

Different patterns are furnished on the CD-ROM.

The structure used is the following one:

Directory: 600M_0.0dBFS
Files: 600M_15.3M_0.0dBFS.txt
600M_264.9M_0.0dBFS.txt
600M_299.1M_0.0dBFS.txt
Etc...

In the above example:

- The name of the directory indicates that Fclock = 600 MHz and the sinewave generated is full scale (0 dBFS).
- The files of this directory indicate first the clock rate (600M) then the Fout Frequency (15.3M) and then the output level (0.0 dBFS).
- All this information is written in the header of the pattern file.

Note: Patterns furnished are at a clock rate of 600 Msps. All these pattern files can be used with other sampling rates. When changing the sampling rate by a factor k, the Fout frequency is modified by the same factor k and the output level remains unchanged.

If the wanted pattern is not available on the CD-ROM, it is possible to generate other patterns with the software furnished (see Section 7).

Section 7


Appendix II: Pattern Generator Software

A pattern generator software is furnished on the CD-ROM. The name of the executable is muxdac10b.exe

It is first necessary to copy this executable file (D:\Patterns\Pattern Generator Software\muxdac10b.exe) on your hard disk. Run this software by double-clicking on *muxdac10b.exe*

A window appears (see Figure 7-1).

Figure 7-1. Pattern Generator User Interface




1. Enter the output level (in dBFS) of the sine wave to be generated.

Note: In single ended: 0 dBFS = Full scale = 1 Vpp = 0.5V peak = -6 dBV = +4 dBm
In differential: 0 dBFS = Full scale = 2 Vpp = 1V peak = 0 dBV = +10 dBm

2. Enter the output frequency (in MHz).

Figure 7-2. Pattern Generator User Interface




3. Enter the Clock rate (in MHz).

Figure 7-3. Pattern Generator User Interface



Figure 7-4. Pattern Generator User Interface



The software calculates the number of cycles $\text{NBSAMPLE} \times \text{Fout} / \text{Fs}$.

In the above example $\text{NBSAMPLE} = 4 \times 500$, $\text{Fout} = 10$ and $\text{Fs} = 600$ so that the number of cycles is 33.3333....

The number of cycles must be an odd integer so that is truncated to 33.

The new Fout value is also $\text{Fout} = 33 \times \text{Fs} / \text{NBSAMPLE} = 9.9 \text{ MHz}$

When the pattern is generated, Figure 7-4 disappears.

Two files are generated in the current directory:

- Volt_file.txt: this is the voltage values associated to each word of the pattern file.
- Pattern_file.txt: this is the pattern file containing 500 vectors of 4 words of 10 bits. It is recommended to rename this file in order to avoid overwriting it when generating another pattern file. To rename the file Pattern_file.txt we recommend the following structure:
 $\text{<Fs value>_<Fout value>_<Vout value>.txt}$
 In the above example, the file name would be 600M_9.9M_0.0dBFS.txt



How to reach us

Home page: www.e2v.com

Sales offices:

Europe Regional sales office

e2v ltd

106 Waterhouse Lane
Chelmsford Essex CM1 2QU
England

Tel: +44 (0)1245 493493

Fax: +44 (0)1245 492492

mailto: enquiries@e2v.com

e2v sas

16 Burospace
F-91572 Bièvres Cedex
France

Tel: +33 (0) 16019 5500

Fax: +33 (0) 16019 5529

mailto: enquiries-fr@e2v.com

e2v gmbh

Industriestraße 29
82194 Gröbenzell
Germany

Tel: +49 (0) 8142 41057-0

Fax: +49 (0) 8142 284547

mailto: enquiries-de@e2v.com

Americas

e2v inc

520 White Plains Road
Suite 450 Tarrytown, NY 10591
USA

Tel: +1 (914) 592 6050 or 1-800-342-5338,

Fax: +1 (914) 592-5148

mailto: enquiries-na@e2v.com

Asia Pacific

e2v ltd

11/F.,
Onfem Tower,
29 Wyndham Street,
Central, Hong Kong

Tel: +852 3679 364 8/9

Fax: +852 3583 1084

mailto: enquiries-ap@e2v.com

Product Contact:

e2v

Avenue de Rochepleine
BP 123 - 38521 Saint-Egrève Cedex
France

Tel: +33 (0)4 76 58 30 00

Hotline:

mailto: hotline-bdc@e2v.com

Whilst e2v has taken care to ensure the accuracy of the information contained herein it accepts no responsibility for the consequences of any use thereof and also reserves the right to change the specification of goods without notice. e2v accepts no liability beyond that set out in its standard conditions of sale in respect of infringement of third party patents arising from the use of tubes or other devices in accordance with information contained herein.